



Side Panel Removal

Step 1 (for right panel only, skip to step 2 for left panel removal.)

- Remove the air control spring by twisting counter-clockwise and pulling.
- Remove the bypass spring by twisting clockwise.

Step 2

- Using a 5/32 Allen wrench, remove the two bolts at the back of the stove.
- Using the 5/32 Allen wrench, loosen but do not remove the three bolts at the front of the stove. These bolts are accessed through small holes in the side of the panel.

Step 3

- Slide the panel forward approximately 1/2 inch to release it from the front three bolts.
- On the right panel only, a twist of the panel may be necessary to clear the bypass handle.

Re-Installation

- Reverse steps for re-installation.
- Do not over tighten bolts
- To reinstall bypass spring, twist counter-clockwise
- To reinstall air control spring, twist counter-clockwise and push.

